

AQUACON Si05/10/20 and SIO2-05/10/20

Process analyzers for silica (Si) and silicic acid (SiO

The AQUACON Si and SIO2 process photometers can be used for the monitoring and control of the Si or SiO ₂ concentration in water. Measurement principle is the photometric determination of dissolved silicic acid after forming of a reduced β-silico-molybdo-acid complex. Main applications for the photometers are the monitoring of the steam quality and the control of ion exchange plants.

The analyzers consist of a control unit with touchscreen and an analysis unit with measuring chamber, valve, dosing pumps and all required tube connections. The control unit includes a microprocessor which controls the automatic measurement incl. sampling, rinsing, reagent dosing and surveillance of the photodetection system.

Your advantages:

- ⇒ Automatic measurement incl. self test and drift compensation
- ⇒ 3 different measurement ranges available for Si and for SiO₂
- ⇒ Easy operation via touchscreen
- ⇒ Adjustable limit value and alarm value
- ⇒ Programmable analog output (0/4-20 mA), optional with USB port for easy data storage
- ⇒ Adjustable break time between two analysis
- ⇒ External start/stop of an analysis possible
- ⇒ No external calibration required
- ⇒ External plug connections (IP65) for alarm relay, limit relay, analysis relais, external start/stop, analog output 0/4-20 mA
- ⇒ Multi range power supply (110–230 Volt, 50–60 Hz)
- ⇒ Including 2-part polycarbonate wall cabinet



Order informations:

AQUACON Si05	(2 – 100 ppb Si)	Order No. 693 2733 01
AQUACON Si10	(2 – 500 ppb Si)	Order No. 693 2734 01
AQUACON Si20	(0,01 – 1,5 ppm Si)	Order No. 693 2735 01
AQUACON SIO2-05	(4 – 200 ppb SiO ₂)	Order No. 693 2733 02
AQUACON SIO2-10	(4 – 999 ppb SiO ₂)	Order No. 693 2734 02
AQUACON SIO2-20	$(0.03 - 3 \text{ ppm SiO}_2)$	Order No. 693 2735 02
Reagent SI-R 1001	(250 ml)	Order No. 101 2735 01
Reagent SI-R 1003	(500 ml)	Order No. 103 2735 01



Technical Data

Current output	0/4 - 20 mA, max. load 500 ohm		
Display	240 x 128 dots, touchscreen		
Relays	1 x Alarm, potential-free 230 V/50 Hz, 3A 1 x Limit, potential-free 230 V/50 Hz, 3A 1 x Analysis state, potential-free 230 V/50 Hz, 3A		
External Switching	potential-free contact, 18 V DC, ca. 4 mA		
Power Supply	110 - 230 V 50/ 60 Hz		
Power Consumption	approx. 16 VA		
Dimensions	640 x 315 x 190 mm (H x W x D)		
Protection	IP 65 (transmitter housing)		
Connections	Plugs with circular connection 1,5 mm ²		
Temperature	5° to 45°C, at consumption of reagents within 6 months		

Since it is company policy to continuously improve its product range, we reserve the right to make changes in the product design without notification to its users.

Specifications

Parameter	Silica/Silicic Acid				
Description	Microprocessor-controlled analyzer for the determination of				
	dissolved silica (Si)/silicic acid (SiO ₂) in water				
Typical Applications	Monitoring and control of steam quality in steam-generating				
	plants. Monitoring and control of ion exchange plants				
Analysis Method:	Photometric determination of the dissolved Si/SiO ₂ by				
	formation of a reduced ß-molybdosilicic acid complex				
Analyzer type	Si05/SiO2-05	Si10/SiO2-10	Si20/SiO2-20		
Measuring Range		2 – 500 ppb Si	0,01 – 1,5 ppm Si		
D 1 (:		4 – 999 ppb SiO ₂			
Resolution	1 ppb	1 ppb	0,01 ppm		
Accuracy	2 % of end value		3 % of end value		
Reproducibility	1 ppb/2 ppb	2 ppb/4 ppb	0,01 ppm/0,02 ppm		
Zero-point Stability	automatic adjustment				
Number of Samples	1				
Sample					
Operating Pressure	0,1 - 10 bar				
Temperature	18 - 30 °C				
Sample Volume	25 ml per analysis (excluding rinsing)				
Sample Condition Chemical Demands	clear, with particles < 0.5 g/l; < 50 µm				
Drain	pH 4-8, PO ₄ ³⁻ ,NH ₃ < Si				
Reagents	pressure free into open drain				
Number	2				
Storage Temp.	10 – 30°C				
Usage/analysis	0,3/1,2 ml				
Reagent volume	250/500 ml				
Suitable for	appr. 400 analysis				
Analysis	11 222 2960				
Cycle (approx.)	13 min., incl. rinsing				
Sample interval	1 – 99 min or external start/stop				



MCC Mariusz Cabała ul. Białobrzeska 33 41-409 Mysłowice tel.: 32-793-40-55 fax: 32-614-10-45 e-mail: biuro@mcc.net.pl